

SHOWMATE

Getting Started Steps for Windows Mobile[®]

1. Get your Registration Code

To use Impatica for PowerPoint Mobile Edition, you will need to obtain registration information. To get your registration information:

1. Go to <http://www.impatica.com/showmate/register>;
2. Fill out the form, including entry of your ShowMate serial number;
3. Print or note the registration information displayed or wait to receive the information via e-mail.

2. Install Impatica for PowerPoint Mobile Edition on your PC

You will need to have Impatica for PowerPoint Mobile Edition installed on your Windows PC to convert and load presentations onto your Windows Mobile handheld. To install it:

1. From the ShowMate CD-ROM, run the Impatica for PowerPoint installer (setupppt.exe) by clicking on the link provided on the ShowMate CD-ROM;
2. Follow the instructions presented in the installation wizard;
3. When the installation is complete, launch Impatica for PowerPoint Mobile Edition;
4. When prompted, enter the registration information e-mailed to you in step 1.

3. Install Impatica Viewer on your Windows Mobile Handheld

The Impatica Viewer for Windows Mobile must be installed on your Windows Mobile handheld before you can load and project presentations. To install it:

1. Connect your Windows Mobile handheld to your Windows PC using the USB cable provided with the handheld and ensure they are connected;
2. Locate and launch the ImpaticaViewerSetup.msi file located in the Impatica Viewers folder on the ShowMate CD-ROM;
3. Follow the instructions presented to complete the installation.

4. Convert and Load your Presentation

To impaticize your PowerPoint presentation and load it onto your Windows Mobile handheld:

1. Click and drag your PowerPoint file onto the Impatica for PowerPoint icon on your desktop or into the Source Presentation files list in Impatica for PowerPoint Mobile Edition;
2. Click *Impaticize*;
3. Preview the converted presentation by clicking *Preview*;
4. Connect your mobile device to your PC and ensure that they are connected;
5. Locate the impaticized version of your presentation **filename.imp**. By default this file will be in the same location as the PowerPoint file;
6. Copy the impaticized presentation to the handheld using Windows Explorer. The Impatica Viewer will search the handheld's *My Documents* folder and its subfolders as well as any available memory stick/card for all impaticized presentation files.

Tip: You may wish to use the ShowMate Practice presentation for Windows Mobile that is included on the ShowMate CD-ROM to practice converting and loading.

5. Project your Presentation

To start projecting your presentation, first connect your ShowMate to the projector or display and to a power supply:

1. Use a VGA cable to connect your ShowMate to your projector or display;
2. Use the supplied power charger and USB cable to plug your ShowMate into a power outlet.

Then, on the Windows Mobile handheld:

1. Ensure that Bluetooth connections have been enabled for your handheld;
2. Launch the Impatica Viewer;
3. Click on the presentation you would like to project and choose **Project**;
4. Choose your ShowMate from the list that appears. If your ShowMate does not appear in the list, add it by selecting **New ShowMate**. The ShowMate will appear as "**ShowMate nnnnnn**" in the device list, where "nnnnnn" corresponds to the last 6 digits in the ShowMate serial number;
5. Enter the passcode if required. The default passcode is the first 4 digits in the last segment of the ShowMate serial number;
6. Once the presentation has finished transferring to the ShowMate, use the presentation menu or shortcut keys to control the presentation.